

Endpoint Detection of Low Open Area Contact Nitride Etches by Use of Optical Emission Spectroscopy in an APC Compatible Multi-Sensor Platform

AEC/APC Asia 2005

<u>Bernard KAPLAN</u>, Eric BLUEM (HORIBA Jobin Yvon) Philippe LE NAOUR, François CUVILLIER (ALTIS)

HORIBAGROUP

Explore the future

ISSION • FLUORESCENCE • FORENSICS • GRATINGS & DEM • OPTICAL SPECTROSCOPY • RAMAN • THIN FIL

Content

1. Context

- ALTIS & HORIBA Jobin Yvon
- The JY instrument platform
- Contact Nitride Etch

2. Optical Emission Spectroscopy

- Data handling
- Wavelength selection
- Endpoint detection

3. Results

Explore the future

- SEM validation
- Statistics : tool impact, first wafer effect ...

HORIBAGRO



ALTIS Semiconductor

Joint Venture (1991) 50% IBM, 50% Infineon 2000 people 10000 wafers per week 504 M€ CMOS logic, eDRAM & mixed signal

HORIBA Group

3700 people worldwide 750 M\$

▶ Jobin Yvon (joined HORIBA 1997)
550 people worldwide
98 M€

► Thin Film Division (50 people) Optical metrology (ellipsometry, APC)



MultiCPM Platform

- In-situ multi-sensor and multi-chamber monitoring
 - OES Optical Emission Spectroscopy
 - LEM Camera Interferometry
 - TDM Depth monitoring
- Designed for fab
- Compatible with all etchers or and OEMs
- 📕 LAM Alliance

Explore the future

- AMAT AME 5000 & 5200
 - TEL Unity 2 & M
- Common Windows based software platform
- More than 50 production chambers equipped at ALTIS



Optical Emission Spectroscopy

- Principle
 - The relaxation of plasma excited species produces light.
 - Emission wavelengths are caracteristic of the species in presence.



HORIBAGROUP

• Instrumentation

- Light is guided towards a diffraction grating by a fiber optic
- Light intensity is measured as a function of wavelength
- Real time

Explore the future

Application to Plasma Etching

- Plasma / etched layer interaction
 - Plasma emission is modified by the nature of the layer being etched

Plasma emission change

- Interface
- Change in the chemical reaction in the plasma
- Appearance / disappearance of emission lines
- Interface signature
 - Rupture

Explore the future



Application to Plasma Etching

- Plasma / etched layer interaction
 - Plasma emission is modified by the nature of the layer being etched

• Plasma emission change

- Interface
- Change in the chemical reaction in the plasma
- Appearance / disappearance of emission lines
- Interface signature
 - Rupture

Explore the future





Application to Plasma Etching

- Plasma / etched layer interaction
 - Plasma emission is modified by the nature of the layer being etched

Plasma emission change

- Interface
- Change in the chemical reaction in the plasma
- Appearance / disappearance of emission lines
- Interface signature
 - Rupture

Explore the future



The Endpoint Transition

- Transition between 2 levels
- Transition time length is related to the etch rate inhomogeneity
 - → Non-uniformity from the center to the border of the wafer (layer thickness ...)
 - → Non-uniformity in pattern density
- Only certain wavelengths are concerned



Contact Nitride Etch

Flash Memory

- 0.22 µm technology, open area 2.5 to 5%, non-uniform pattern density
- 5 steps involved : Nitride dep / oxide dep / CMP / (litho mask) / oxide etch /nitride etch
- Nitride etch monitored by OES



The Process Engineer's Work

Step 1: endpoint detection setting

- Collect & understand the data
- Select wavelengths & parameter endpoint detection algorithm
- Perform test on a few lots

Step 2: validation

Explore the future

- Process monitor (still in fixed time)
- Statistics and correlation with electrical tests
- Step 3: production and yield improvement



JY solutions

1. Understanding the data

- Quick navigation
- Classification

2. Select Wavelength

The software selects the best wavelengths from a series of runs

3. Parameter setting

- Easy and intuitive algorithm parametering

4. Validation

Explore the future

- Statistics in a database
- Reprocessing on the saved spectra (change the algorithm parameters)

HORIBAGRO

Classification

• Principle

 Bring together wavelengths that behave in a similar manner and make groups with them

Result

- The classification offers within a few seconds a summary of the 2048 wavelengths
- The user can understand quickly what is happening in the process, where it is happening and when



A classification example ...



Explore the future

MISSION • FINORESCENCE • FORENSICS • GRATINGS & OFM • OPTICAL SPECTROSCOPY • RAMAN • THIN FI

Wavelength selection

User inputs •Time range •Wavelength range

► The algorithm automatically selects the best wavelengths

Image Bottom : selected wavelengths are in red Top : average kinetics over selected kinetics



HORIBAGROUP

Explore the future

The endpoint detection algorithm in sequence

- •The top curve is the average kinetics
- •The bottom curve tells if the rupture is well defined
- •The left vertical black line on top points to the most highly probable rupture time
- •The right vertical black line is the time

Explore the future



The endpoint is not reached yet, the probability to find an rupture (bottom curve) is still low.

•

•

Explore the future

•



•

The endpoint is being reached. The probability start to grow but it is still low: the endpoint can be detected but it is *not robust* !

•

Explore the future

•



The endpoint is detected. The probability is high and has reached the user defined threshold (value 10). The endpoint detection robustness has increased.

Explore the future



The endpoint has long been reached. The algorithm still points towards the rupture point at 70 seconds.

•



•

Explore the future

•

BE 40/1 10" BORD FFB280

SEM Validation & Over-etch

- At rupture time (10s) Dense zone are already open — ... but electrical test fails At rupture time +15s - The land is being etched - ... but electrical test still fails At rupture time +30s - Good! At rupture time +40s N:31433 F A_C O Not good again
- S5002 5.0 kV X50.0k' 600nm

HORIBAGROUP

Explore the future

Statistics

Collected data

- Monitoring (endpoint not in production yet)
- 10000 runs (1 month)
- SECS II
- Chamber names for the previous steps
- Study

Explore the future

- Endpoint "normal" variability
- Tool or chamber impact on endpoint variability

HORIBAGROUP

- Maintenance operation

Endpoint variability

- Average 12 s
- Standard deviation 2.3 s
- 50 % between 6.8 and 17.6 s
- Some outliers above 20 s (under investigation)

The endpoint can vary within a range of 10 s. This is to be related to the wafer to wafer nitride layer thickness variability



First wafer effect 1/3

- Nitride layer etch
 - One tool, two chambers (A & B)
 - Average rupture time vs slot number
 - Two populations : odd and even slots



First wafer effect 2/3

- Nitride layer etch
 - One tool, two chambers (A & B)
 - Average rupture time vs slot number
 - Two populations : odd and even slots
 - Chamber effect ! Odd slot numbers are usually processed by chamber A
 - Problem ?



First wafer effect 3/3

- Nitride layer etch
 - One tool, two chambers (A & B)
 - Average rupture time vs slot number
 - Two populations : odd and even slots
 - Chamber effect ! Odd slot numbers are usually processed by chamber A
 - Problem ?
 - temperature and flow correction in the tool cooling system



Tool Matching

• Previous step : oxide layer etch

- 2 tools : T1 and T2
- Separate study on nitride etcher chamber A and B
- Results
 - Significant difference between T1 and T2
 - T1 is more selective than T2 : T2 starts to etch the nitride layer so the endpoint comes sooner on T2 than on T1.



Advanced Process Control at ALTIS

Process monitoring

Increase process stability

• Equipment monitoring

- Increase equipment uniformity and performance
- Tool matching
- Module monitoring
 - Control the inter-dependent steps of a module
- HORIBA Jobin Yvon is a key partner for the OES process control at ALTIS

